

NIST
PUBLICATIONS

REFERENCE

NISTIR 6647

Properties of a 50/50 Mixture of Jet-A + S-8

Thomas J. Bruno
Arno Laesecke
Stephanie L. Outcalt
Hans-Dieter Seelig
Beverly L. Smith

NIST

National Institute of Standards and Technology
Technology Administration, U.S. Department of Commerce

NISTIR 6647

Properties of a 50/50 Mixture of Jet-A + S-8

Thomas J. Bruno
Arno Laesecke
Stephanie L. Outcalt
Hans-Dieter Seelig
Beverly L. Smith

*Thermophysical Properties Division
325 Broadway
Boulder, CO 80305*

March 2007



U.S. Department of Commerce
Carlos M. Gutierrez, Secretary

Technology Administration
Robert Cresanti, Under Secretary for Technology

National Institute of Standards and Technology
William Jeffrey, Director

Executive Summary

- Report of the chemical analyses of Jet-A and S-8 (samples received from AFRL).
- Report of the distillation curves of 50/50, 25/75 and 75/25 Jet-A + S-8.
- Report of density survey measurements of 50/50 Jet-A + S-8.
- Report of viscosity survey measurements of 50/50 Jet-A + S-8.
- Report of speed of sound survey measurements of 50/50 Jet-A + S-8.
- Report of compressed liquid density measurements of 50/50 Jet-A + S-8.

Contents

1. Introduction.....	1
2. Chemical Analysis of Jet-A and S-8.....	2
3. Distillation Curves of Jet-A + S-8	6
4. Density (at Atmospheric Pressure) for 50/50 Jet-A + S-8	14
5. Viscosity (at Atmospheric Pressure) for 50/50 Jet-A + S-8	19
6. Speed of Sound Measurement (at Atmospheric Pressure) for 50/50 Jet-A + S-8	23
7. Correlations for the Density, Viscosity, and Speed of Sound of 50/50 Jet-A + S-8.....	27
8. Compressed Liquid Density Measurements for 50/50 Jet-A + S-8	28
9. References.....	31

Properties of a 50/50 Mixture of Jet-A + S-8*

Thomas J. Bruno, Arno Laesecke, Stephanie L. Outcalt
Hans-Dieter Seelig, and Beverly L. Smith

National Institute of Standards and Technology
325 Broadway
Boulder, Colorado 80305

This report describes measurement efforts performed on mixture(s) of aviation fuels: Jet-A + S-8. The primary mixture is a 50/50 (vol/vol) combination of the two fuels. Measurements include chemical analysis, density, viscosity, speed of sound and vapor pressure (by a distillation curve measurement). This document compiles in one source the available measured data for the mixture.

Keywords: density; distillation curve; speed of sound; thermal conductivity; vapor pressure; viscosity

1. Introduction

The major gas turbine fuel that is currently the most common fuel used by the United States military is JP-8 (MIL-DTL-83133), a kerosene fraction that has a higher flash point than the main military predecessor, JP-4 [1]. JP-8 was first introduced at NATO bases in 1978, hence it was also called NATO F-34, and is currently the U.S. Air Force's primary fuel, and the primary fuel for U.S. Navy shore-based aviation. Aboard aircraft carriers, the major fuel is JP-5, which has an even higher flash point (desirable for safety considerations), although its higher cost restricts its use to the specialized fire control needs of aircraft carriers. JP-8 is very similar to Jet A-1, the most common commercial gas turbine fuel, with the major differences being in the additive package. JP-8 contains an icing inhibitor, corrosion/lubricity enhancer and anti-static additive. Jet-A (U.S. domestic commercial jet fuel) differs from Jet-A1 (non-U.S. commercial jet fuel) primarily in freezing point ($-40\text{ }^{\circ}\text{C}$ as opposed to $-47\text{ }^{\circ}\text{C}$, respectively). The understanding of the properties of JP-8 must necessarily begin with understanding the properties of Jet-A, since the fluids are very similar and because the additive package is often varied to suit applications, climatic regions, and supply streams.

Environmental concerns, and the potential of disruptions in supply, have led to the development of new aviation fuels based on the Fischer Tropsch process. One such fuel made from natural gas is designated as S-8 (the "S" referring to synthetic; CAS No. 437986-20-4) [2]. This fluid, which is intended as a synthetic JP-8, is a hydrocarbon mixture rich in C7 to C18 linear and branched

* Note: In order to describe materials and experimental procedures adequately, it is occasionally necessary to identify commercial products by manufacturers' names or labels. In no instance does such identification imply endorsement by the National Institute of Standards and Technology, nor does it imply that the particular product or equipment is necessarily the best available for the purpose.

alkanes. It has a flash point range between 37.8 °C and 51.8 °C, an auto ignition temperature of 210 °C, and explosive limits in air between 0.7 and 5 (vol/vol). It is clear in appearance (no dye is added to current formulations) and somewhat lower in density, viscosity, and speed of sound transmission than typical formulations of Jet-A and JP-8. It is likely that initial applications of S-8 will be in formulations mixed with either JP-8 or Jet-A. In view of the comments above on the differences between Jet-A and JP-8, the AFRL desired measured properties of a 50/50 (vol/vol) mixture of Jet-A and S-8 to guide formulations of test fuel mixtures. This document summarizes the measurements done at NIST on this mixture.

The samples of Jet-A and S-8 were obtained from AFRL. The sample of Jet-A was designated POSF-4658, and was a composite sample that was prepared by AFRL from several samples from several manufacturers. The S-8 was designated POSF-4734. The 50/50 (vol/vol) mixtures were prepared volumetrically at ambient temperature (approximately 23 °C) and atmospheric pressure (approximately 83.2 kPa) by use of mixing cylinders. The uncertainty in the volume during the preparation of mixtures was 0.1 mL. For the remainder of this report, we will commonly refer to the resulting mixture as Jet-A + S-8, or simply as “the mixture.”

2. Chemical Analyses of Jet-A and S-8

A sample of Jet-A, designated as POSF-4658, was presented for analysis. This sample is a composite made from a number of individual lots of Jet-A. The sample was drawn with a disposable pipette from a half-gallon steel pail supplied by AFRL. The sample had a very pale yellow cast, and did not appear to have any dyeing agent. The sample appeared to have a viscosity and odor typical of kerosenes.

The sample was analyzed with a gas chromatography–mass spectrometry method. A 30 m capillary column with a 0.1 µm coating of 5 % phenyl polydimethyl siloxane was chosen as the stationary phase [3]. This phase provides separations based upon boiling temperature and also the polarity of the solute. In this context, polarity also includes points of unsaturation or aromaticity on the solute molecule. Sample was injected via syringe into a split/splitless injector set with a 100 to 1 split ratio. The injector was operated at a temperature of 350 °C and a constant head pressure of 8 psig. The sample residence time in the injector was very short; thus the effect of sample exposure to this high temperature is expected to be minimal. The column was temperature programmed to provide complete and rapid elution with minimal loss of peak shape. Initially, the temperature was maintained isothermally at 60 °C for 2 min, followed by a 2 °C/min ramp to 90 °C, followed by a 10 °C/min ramp to 250 °C. Although the analysis was allowed to run for 40 min, all peaks were eluted after approximately 27 min. Mass spectra were collected for each peak from 15 to 550 RMM units [4]. Integration of the areas under each peak was done with a commercial algorithm optimized to identify peaks that were at least an order of magnitude larger than the noise level.

Before any analysis was done, the mass spectrometer was tuned with a sample of perfluoro-tributyl amine [3]. Then, after the tune settings were optimized, a blank run was done to ensure the absence of extraneous or ghost components, and to determine stationary phase background.

Table 1. The analysis of Jet-A by gas chromatography–mass spectrometry.

Peak no.	Retention time, min	Peak profile	Correlation coefficient	Confidence	Name	CAS No.	Area percentage
A	1.726	S	72.9	H	n-heptane	142-82-5	0.125
B	1.878	S	76.9	H	methyl cyclohexane	108-87-2	0.198
C	2.084	S	71.6	H	2-methyl heptane	592-27-8	0.202
1	2.144	S	29.2	H	toluene	108-88-3	0.320
D	2.223	S	41.9	H	cis-1,3-dimethyl cyclohexane	638-04-0	0.161
2	2.351	S	44.0	H	n-octane	111-65-9	0.386
E	2.945	S	31.1	H	1,2,4-trimethyl cyclohexane	2234-75-5	0.189
3	3.036	S	12.4	H	4-methyl octane	2216-34-4	0.318
4	3.169	S	37.6	H	1,2-dimethyl benzene	95-47-6	0.575
5	3.527	S	33.9	H	n-nonane	111-84-2	1.030
6	3.921	S	NA	U	?		0.321
7	4.066	S & A	NA	H	x-methyl nonane	NA	0.597
8	4.576	S & A	7.97	M ^a	4-methyl nonane	17301-94-9	0.754
9	4.655	S	35.8	H	1-ethyl-3-methyl benzene	620-14-4	1.296
10	4.764	S	10.7	H	2,6-dimethyl octane	2051-30-1	0.749
11	4.836	A	5.27	U ^b	1-methyl-3-(2-methylpropyl) cyclopentane	29053-04-1	0.285
12	5.012	S	27.8	M ^b	1-ethyl-4-methyl benzene	622-96-8	0.359
13	5.049	A	13.7	M ^b	1-methyl-2-propyl cyclohexane	4291-79-6	0.370
14	5.291	S	26.3	H	1,2,4-trimethyl benzene	95-63-6	1.115
15	5.325	S	37.7	H	n-decane	124-18-5	1.67
16	5.637	S	36	H	1-methyl-2-propyl benzene	1074-17-5	0.367
17	5.825	S	36	H	4-methyl decane	2847-72-5	0.657
18	5.910	S	26.9	H	1,3,5-trimethyl benzene	108-67-8	0.949
19	6.073	S & A	NA	M	x-methyl decane	NA	0.613
20	6.176	S	5.01	M ^b	2,3-dimethyl decane	17312-44-6	0.681
21	6.364	S & A	25.7	M ^b	1-ethyl-2,2,6-trimethyl cyclohexane	71186-27-1	0.364
22	6.516	S & A	35.6	H	1-methyl-3-propyl benzene	1074-43-7	0.569
F	6.662	S & A	NA	U ^b	aromatic	NA	0.625
23	6.589	S	20.4	M ^c	5-methyl decane	13151-35-4	0.795
24	6.728	S	22.9	H	2-methyl decane	6975-98-0	0.686
25	6.862	A	23.2	H	3-methyl decane	13151-34-3	0.969
26	7.110	S	NA	U	Aromatic	NA	0.540
27	7.159	S	NA	U	Aromatic	NA	0.599
28	7.310	S	17.9	M	1-methyl-(4-methylethyl) benzene	99-87-6	0.650
29	7.626	A	22.0	H	n-undecane	1120-21-4	2.560
29	7.971	A	NA	M	x-methyl undecane	NA	1.086
30	8.875	A	22.3	M	1-ethyl-2,3-dimethyl benzene	933-98-2	1.694
31	9.948	A	19.6	H	n-dodecane	112-40-3	3.336
32	10.324	S	19.0	H	2,6-dimethyl undecane	17301-23-4	1.257
33	12.377	S & A	10.8	H	n-tridecane	629-50-5	3.998
33a	12.901	S	24.1	M	1,2,3,4-tetrahydro-2,7-dimethyl naphthalene	13065-07-1	0.850
33b	13.707	S	3.5	M	2,3-dimethyl dodecane	6117-98-2	0.657
33c	14.138	S	14.5	M	2,6,10-trimethyl dodecane	3891-98-3	0.821
33d	13.834	S	NA	M	x-methyl tridecane	NA	0.919
33e	13.998	S	NA	M	x-methyl tridecane	NA	0.756
34	14.663	S	29.8	H	n-tetradecane	629-59-4	1.905
35	16.86	S	24.7	H	n-pentadecane	629-62-9	1.345

^a Trailing impurity

^b Highly impure composite peak

^c There is evidence of an aromatic impurity in this peak, coeluting

The results of the analysis are provided in Table 1. The numbered peaks are the largest peak areas recorded on the total ion chromatogram (1 % or higher). Note that these areas are raw areas and have not been calibrated with a standard. Lettered peaks are for components between 0.7 and 1 %, provided the chromatography is good. Double lettered peaks are very early eluting components that were included to provide a suite of light components for potential future model development. These peaks were chosen in part for their elution order and chromatographic purity.

A sample of S-8, designated POSF 4734, was presented for analysis. The sample was drawn with a disposable pipette from a half-gallon steel pail supplied by the AFRL. Approximately 0.5 mL of the fluid was drawn and stored in a tightly capped scintillation vial until used. The liquid sample was clear, and appeared to have a viscosity lower than that of a typical kerosene. The liquid had little discernable odor. The same method used for Jet-A was applied for the analysis of S-8. The results of this analysis are provided in Table 2.

A number of clear differences may be seen in the chemical analyses. First, the sample of Jet-A has a typical kerosene composition in that a number of aromatic constituents can be observed. No aromatic constituents are listed in Table 2 for S-8. Indeed, no aromatics were detected in S-8 in any of the analyses that were performed. A second striking feature is the large number of linear or simple branched alkanes that are present in S-8, in contrast to the more complex constituents found in Jet-A. This is not surprising considering that the feed stock of S-8 is a paraffinic wax derived by the Fischer-Tropsch process from natural gas. This paraffinic wax is cracked and extensively isomerized to obtain the S-8 jet fuel.

The samples of Jet-A and S-8 were further examined for hydrocarbon types by use of a mass spectrometric classification method summarized in ASTM Method D-2789 [5]. In this method, one uses mass spectrometry (or gas chromatography–mass spectrometry) to characterize hydrocarbon samples into six types. The six types or families are paraffins, monocycloparaffins, dicycloparaffins, alkylbenzenes (or aromatics), indanes and tetralins (grouped as one classification), and naphthalenes. Although the method is specified only for application to low olefinic gasolines, it is of practical relevance to many complex fluid analyses, and is often applied to gas turbine fuels, rocket propellants, and missile fuels. The uncertainty of this method, and the potential pitfalls, are discussed elsewhere. For the hydrocarbon type analysis of the distillate fraction samples, 1 μ L samples were injected into the GC-MS. Because of this consistent injection volume, no corrections were needed for sample volume. The results of these analyses are provided in Table 3.

Table 2. Detailed analysis for S-8, POSF 4734, provided by AFRL. The peak lettering and numbering scheme are described in the text.

Peak no.	Retention time, min	Peak profile	Correlation coefficient	Confidence	Name	CAS No.	Area percentage
aa	2.119	S	72.2	H	2-methyl heptane	592-27-8	0.32
bb	2.162	A	41.4	H	3-methyl heptane	589-81-1	0.43
a	2.310	A	26.3	H	1,2,3-trimethyl cyclopentane	15890-40-1	0.96
1	2.564	A	44.2	H	2,5-dimethyl heptane	2216-30-0	1.13
2	2.803	A	33.9	H	4-methyl octane	2216-34-4	2.506
3	2.869	A	16.9	H	3-methyl octane	2216-33-3	1.323
4	3.123	A	21.6	H	n-nonane	111-84-2	1.623
5	3.358	A	18.5	M	3,5-dimethyl octane	15869-96-9	1.035
b	3.456	A	29.0	H	2,6-dimethyl octane	2051-30-1	0.756
6	3.682	A	54.4	H	4-ethyl octane	15869-86-0	1.032
7	3.757	A	39.8	H	4-methyl nonane	17301-94-9	1.904
8	3.792	S	39.2	H	2-methyl nonane	871-83-0	1.019
9	3.866	A	26.9	H	3-methyl nonane	5911-04-6	1.385
10	4.186	A	51.4	H	n-decane	124-18-5	2.050
11	4.390	A	16.7	M	2-5-dimethyl nonane	17302-27-1	1.175
12	4.750	S	12.0	M	5-ethyl-2-methyl octane	62016-18-6	1.015
13	4.820	A	37.7	H	5-methyl decane	13151-35-4	1.315
14	4.859	A	42.1	H	4-methyl decane	2847-72-5	1.134
15	4.902	A	35.4	H	2-methyl decane	6975-98-0	1.529
16	4.980	A	44.1	H	3-methyl decane	13151-34-3	1.583
17	5.312	A	50.1	H	n-undecane	1120-21-4	2.420
c	5.484	A	NA	M	x-methyl undecane	NA	1.590
18	5.664	A	11.9	M	3-methyl undecane	1002-43-3	1.15
19	5.906	A	37.3	H	5-methyl undecane	1632-70-8	1.696
20	5.949	A	29.5	H	4-methyl undecane	2980-69-0	1.045
21	5.996	A	15.1	M	2-methyl undecane	7045-71-8	1.072
22	6.074	A	7.9	U	2,3-dimethyl undecane	17312-77-5	1.213
23	6.387	A	43.9	H	n-dodecane	112-40-3	2.595
d	6.606	A	8.3	M	4-methyl dodecane	6117-97-1	0.929
e	6.668	A	NA	H	x-methyl dodecane	NA	0.744
24	7.024	S	28.7	H	2-methyl dodecane	1560-97-0	1.293
25	7.094	S	NA	M	x-methyl dodecane	NA	1.281
28	7.383	A	36.0	H	n-tridecane	629-50-5	1.739
f	7.923	A	8.7	U	4-methyl tridecane	26730-12-1	0.836
29	7.970	A	9.8	U	6-propyl tridecane	55045-10-8	1.052
30	8.040	A	NA	M	x-methyl tridecane	NA	1.066
31	8.306	A	23.3	H	n-tetradecane	629-59-4	1.562
32	8.396	A	NA	M	x-methyl tetradecane	NA	1.198
g	8.490	S	6.4	M	5-methyl tetradecane	25117-32-2	0.720
33	8.728	S	10.2	H	n-pentadecane	629-62-9	1.032
H	9.232	A	NA	M	x-methyl tetradecane	NA	0.727

Table 3. A summary of the hydrocarbon type analysis as provided by ASTM D-2789, for Jet-A-4658 and S-8-4734.

Fluid	Paraffins	Monocyclo- paraffins	Dicyclo- paraffins	Alkyl- aromatics	Indanes and tetralins	Naphth- alenes
	Vol %	Vol %	Vol %	Vol %	Vol %	Vol %
Jet-A- 4658	46.5	22.5	5.4	18.4	4.5	2.4
S-8- 4734	80.0	17.3	0.9	0.1	0	1.9

Especially striking is the paraffin content, which for S-8 is 80 % as compared with 46.5 % for Jet-A. Also striking is the difference in the aromatic fraction (which is consistent with the observation made earlier from the detailed analyses presented in Tables 1 and 2). The alkyl-aromatic content result for Jet-A was 18.4 %, while for S-8 it is negligible. In addition, S-8 has no discernable indanes or tetralins by ASTM-D-2789.

3. Distillation Curves of Jet-A + S-8

One of the most important methods of characterizing complex fluids is the measurement of the distillation curve. Simply stated, the distillation curve is a plot of the distillation temperature of the fluid plotted against the volume fraction distilled [6]. We have recently introduced an advanced approach to the measurement of the distillation curve that takes the information content to a much higher level [7-14]. The new metrology provides:

- actual onset of boiling temperatures (the vapor rising temperature),
- a composition explicit data channel for each distillate fraction (for both qualitative and quantitative analysis),
- temperature measurements that are true thermodynamic state points, termed T_k
- the energy content of each distillate fraction,
- consistency with a century of historical data, presented as T_h
- explicit identification of azeotropes in fractions,
- trace chemical analysis of each distillate fraction, and
- corrosivity assessment of each distillate fraction.

Distillation curves were measured for several mixtures of Jet-A + S-8 (25/75, 50/50 and 75/25, Jet-A + S-8, vol/vol). The mixture concentrations listed are nominal values mainly for identification purposes, however the uncertainty in preparation of the mixtures with mixing cylinders was 0.1 mL. The onset of boiling behavior of the mixtures is presented first in Table 4. In this table, the temperatures have been corrected to what would be obtained at 1 atmosphere, with the modified Sidney Young equation [6, 15-17]:

$$C_c = C(760 - P_a)(273 + T_c),$$

Table 4. The onset of boiling behavior for three mixtures of Jet-A + S-8.

Observed temperature, °C	S-8	75/25 S-8 + Jet-A	50/50 S-8 + Jet-A	25/75 S-8 + Jet-A	Jet-A 4658
Onset	163.0	160.9	154.9	161.8	139.9
Sustained	168.6	182.3	178.6	178.9	185.6
Vapor rising	181.9	184.8	186.6	189.1	190.5

where C_c is the correction added to the observed temperature, C is a constant, 0.00012, P_a is the atmospheric pressure in millimeters of mercury, and T_c is the measured temperature in centigrade. In fact, the original Sidney Young equation specifies that C_c is dependent upon the average hydrocarbon chain length of the fluid, ranging from 0.000135 for a single carbon to 0.000119 for 8 carbons. A linear correlation of these factors can be used to predict a value for simple fluids. In this work, C was set to 0.000109 [15-17], a value that corresponds to a carbon chain of 12. The actual experimental pressures were 83.5 kPa, 82.4 kPa, and 83.7 kPa for the 75/25, 50/50, and 25/75 mixtures, respectively. From these data and the corrected temperatures, one can recover the raw measured temperatures with the Sidney Young equation.

Representative distillation curve data for the three mixtures of Jet-A with S-8, along with data for the starting materials, are presented in Table 5. In this table we provide both T_k and T_h (where T_k is measured directly in the fluid while T_h is measured in the distillation head). The T_k value is a true thermodynamic state point that can be modeled theoretically, while the T_h data allow comparison with earlier measurements made with typical distillation curve instrumentation. In this table, the estimated uncertainty in the temperatures (with a coverage factor $k = 2$) is 0.1 °C. Note that the experimental uncertainty of T_k is actually somewhat lower than that of T_h , but as a conservative position, we use the higher value for both temperatures. The uncertainty in the volume measurement that is used to obtain the distillate volume fraction is 0.05 mL in each case.

The distillation curves based on the data from Table 5 are presented in Figure 1. The shapes of all of the curves are of the subtle sigmoid type that one would expect for a highly complex fluid with many components, distributed over a large range of relative molecular mass. There is no indication of the presence of azeotropic constituents, since there is an absence of multiple inflections and curve flattening.

The relationship between T_k and T_h is presented in Figure 2, in which both temperatures are presented for the mixture data shown in Table 2. We note that T_k always leads T_h . This behavior is consistent with a complex mixture with a continually changing composition. Note that when these two temperatures converge, it is evidence of either a single component being generated (by vaporization) in the kettle, or the presence of an azeotrope that controls the composition of both phases. The absence of such a convergence in Figure 2 can be interpreted as further evidence of the absence of azeotropic behavior. This is in contrast to what was observed for the gasoline oxygenates, in which the convergence of T_k and T_h (due to azeotrope formation) was observed [12].

Table 5. Representative distillation curve data for the three mixtures of S-8 + Jet-A-4658 measured in this work. For reference, the data for the individual components, S-8 and Jet-A-4658, are also provided. In this table, the temperatures have been corrected to what would be obtained at 1 atmosphere, with the modified Sidney Young equation. These data are plotted in Figure 1.

Distillate volume fraction, %	S-8		75/25 S-8 + Jet-A		50/50 S-8 + Jet-A		25/75 S-8 + Jet-A		Jet-A 4658	
	T _k , °C	T _h , °C	T _k , °C	T _h , °C	T _k , °C	T _h , °C	T _k , °C	T _h , °C	T _k , °C	T _h , °C
5	183.6	169.2	187.8	176.2	190.2	171.0	193.3	174.7	195.4	174.7
10	185.0	173.9	190.4	180.8	192.8	177.6	196.4	183.2	198.5	183.3
15	187.7	179.1	193.4	184.2	196.4	183.6	199.9	189.3	201.5	187.0
20	190.2	173.6	196.3	182.6	199.9	188.9	202.9	192.5	204.7	189.1
25	193.0	175.5	199.8	187.5	203.5	184.8	206.6	189.6	208.1	190.6
30	196.2	181.9	202.8	191.1	206.3	192.7	209.6	193.1	211.3	192.8
35	199.5	187.7	206.3	194.5	209.9	193.3	212.7	196.5	214.3	194.6
40	202.9	192.0	209.9	197.5	213.3	193.8	216.4	198.4	217.6	199.1
45	207.1	196.2	213.7	198.1	217.1	196.6	219.7	200.8	220.7	202.6
50	211.0	200.3	218.2	205.8	221.1	201.8	223.6	207.2	224.2	205.4
55	215.3	205.2	222.4	210.4	225.1	206.9	227.5	211.3	227.6	208.6
60	219.6	209.3	226.6	214.6	228.8	208.1	231.0	215.3	231.2	212.4
65	224.2	213.6	231.6	219.4	233.3	213.1	235.0	219.9	234.7	214.9
70	229.4	219.1	236.4	225.8	237.2	220.0	238.9	221.2	239.4	216.6
75	235.2	224.3	241.8	229.2	242.3	221.1	243.7	226.5	243.3	218.7
80	240.1	231.4	247.5	233.9	247.2	225.8	248.8	233.2	247.9	220.8
85	246.8	236.8	255.4	240.7	254.4	231.5	255.7	235.5	253.6	224.1




Figure 1. Representative distillation curves for each of the three mixtures of S-8 + Jet-A-4658 with the curves for the individual components, S-8 and Jet-A-4658, also provided.




Figure 2. The relationship of T_k and T_h for the three mixtures of S-8 + Jet-A-4658 measured in this work.

While the gross examination of the distillation curves is instructive and valuable for many design purposes, the composition channel of the advanced approach can provide even greater understanding and information content. One can sample and examine the individual fractions as they emerge from the condenser, as discussed in the introduction. Following the analytical procedure described, samples were collected and prepared for analysis. Chemical analyses of each fraction were done by gas chromatography with flame ionization detection and mass spectrometric detection. Representative chromatograms (measured by flame ionization detection) for each fraction of Jet-A-4658 are shown in Figure 3. The time axis is from 0 to 12 min for each chromatogram, and the abundance axis is presented in arbitrary units of area counts (voltage slices). It is clear that although there are many peaks on each chromatogram (30 to 40 major peaks, and 60 to 80 minor and trace peaks), these chromatograms are much simpler than those of the neat fluids, which can contain 300 to 400 peaks. At the very start of each chromatogram is the solvent front, which does not interfere with the sample. One can follow the progression of the chromatograms in Figure 3 as the distillate fraction becomes richer in the heavier components. This figure illustrates just one chemical analysis strategy that can be applied to the distillate fractions. It is possible to use any analytical technique that is applicable to solvent-borne liquid samples that might be applicable to a given application.

The distillate fractions of the three Jet-A + S-8 mixtures, along with the starting Jet-A and S-8 fluids, were examined for hydrocarbon types by use of a mass spectrometric classification method summarized in ASTM Method D-2789 [5]. The results of these hydrocarbon type analyses are presented in Tables 6a to 6d, and plotted in Figure 4. The first line in each of the tables reports the results of the analysis as applied to the entire sample (called the composite) rather than to distillate fractions. The data listed in this line are actually averages of two separate determinations; one done with a neat sample of the fuel (that is, with no added solvent) and the other with the sample in n-hexane. The volume of the neat sample was 0.2 μL , and only these mass spectra were corrected for sample volume. All of the distillate fractions presented in the table were measured in the same way as the composite (m/z range from 15 to 550 RMM units gathered in scanning mode, each spectrum corrected by subtracting trace air and water peaks).

In general, the hydrocarbon type fractions for the composite (the first row in each table) are consistent with the compositions obtained for the distillate fractions (the remaining rows of each table). Thus, taking the S-8 fluid as an example, the paraffin fraction for the composite sample was found to be 80.0 %, while the fractions ranged from 79.1 to 87.8. We have noted, however, that with the composite samples (which naturally produce a much more complex total ion chromatogram), one obtains many more non-integral m/z peaks on the mass spectrum. Thus, for a distillate fraction, one might obtain a peak at m/z = 43.0, while for the composite one might obtain m/z = 43.0, 43.15, etc., despite the resolution of the instrument being only 1 unit of mass. Our practice has been to round the fractional masses to the nearest integral mass, a practice that can sometimes cause bias. This is an unavoidable vagary of the instrument that can potentially be remedied with a higher resolution mass spectrometer. We maintain that the comparability among the distillate fractions is not affected by this characteristic, although the intercomparability between the distillate fractions and the composite should be approached with a bit more caution.




Figure 3. Chromatograms of distillate fractions of Jet-A-4658, presented in arbitrary units of intensity (from a flame ionization detector) plotted against time.

Table 6. Summary of the results of hydrocarbon family calculations based on the method of ASTM D-2789.

Table 6a. 75/25 S-8/Jet-A.

Distillate volume fraction, %	Paraffins Vol %	Monocyclo- paraffins Vol %	Dicyclo- paraffins Vol %	Alkyl- aromatics Vol %	Indanes and tetralins Vol %	Naphth- alenes Vol %
<i>Composite</i>	75.3	22.0	0.4	1.2	0.2	0.9
0.025	74.1	22.2	0.2	3.2	0.0	0.3
10	77.9	19.1	0.1	2.6	0.0	0.3
20	76.7	19.9	0.1	2.9	0.0	0.4
30	76.6	20.0	0.1	2.9	0.0	0.5
35	77.6	19.2	0.1	2.7	0.0	0.4
40	75.9	20.1	0.3	3.0	0.2	0.6
45	81.5	16.3	0.0	1.9	0.0	0.2
50	78.1	18.9	0.2	2.3	0.1	0.5
60	78.9	18.4	0.1	1.7	0.1	0.7
70	72.3	21.6	1.4	2.3	0.8	1.6
80	84.1	15.2	0.0	0.1	0.0	0.6
Residue	83.1	16.5	0.0	0.0	0.0	0.4

Table 6b. 50/50 S-8/Jet-A.

Distillate volume fraction, %	Paraffins Vol %	Monocyclo- paraffins Vol %	Dicyclo- paraffins Vol %	Alkyl- aromatics Vol %	Indanes and tetralins Vol %	Naphth- alenes Vol %
<i>Composite</i>	65.4	23.5	6.1	8.8	3.0	2.3
0.025	66.7	22.9	0.4	9.6	0.0	0.3
10	67.9	23.3	0.5	7.8	0.2	0.4
20	68.9	22.3	0.5	7.7	0.2	0.4
30	70.6	20.9	0.3	7.4	0.3	0.5
35	70.8	20.9	0.4	7.1	0.3	0.4
40	71.3	20.5	0.4	6.8	0.4	0.6
45	73.2	19.3	0.3	6.4	0.3	0.5
50	71.9	20.0	0.4	6.2	0.8	0.8
60	70.4	21.7	0.6	5.2	1.1	1.0
70	73.1	20.9	0.4	3.4	1.0	1.2
80	76.9	19.4	0.1	1.5	0.9	1.2
Residue	72.3	25.9	0.3	0.2	0.1	1.2

Table 6c. 25/75 S-8/Jet-A.

Distillate volume fraction, %	Paraffins Vol %	Monocyclo- paraffins Vol %	Dicyclo- paraffins Vol %	Alkyl- aromatics Vol %	Indanes and tetralins Vol %	Naphth- alenes Vol %
<i>Composite</i>	48.1	25.6	8.5	11.3	4.2	2.5
0.025	56.2	26.5	1.3	15.3	0.4	0.3
10	56.7	25.1	1.5	15.5	0.7	0.5
20	60.9	22.3	0.7	15.2	0.5	0.5
30	56.7	24.6	1.8	14.5	1.6	0.8
35	58.1	23.9	1.5	14.1	1.6	0.8
40	57.0	24.9	1.9	13.3	1.9	1.0
45	59.9	23.6	1.2	12.4	1.8	1.1
50	60.7	23.4	1.3	11.5	1.9	1.2
60	65.5	21.5	0.6	8.9	2.1	1.4
70	62.4	24.9	1.3	6.9	2.6	1.9
80	59.9	27.1	2.7	4.9	3.0	2.4

Table 6d. Jet-A 4658.

Distillate volume fraction, %	Paraffins Vol %	Monocyclo- paraffins Vol %	Dicyclo- paraffins Vol %	Alkyl- aromatics Vol %	Indanes and tetralins Vol %	Naphth- alenes Vol %
<i>Composite</i>	46.5	22.5	5.4	18.4	4.5	2.4
0.025	40.4	27.3	3.4	27.3	1.2	0.5
10	39.8	25.1	4.5	27.2	2.6	0.8
20	41.2	24.6	4.4	25.6	3.1	1.1
30	40.9	25.2	5.8	22.1	4.3	1.6
35	43.2	24.5	4.3	21.9	4.2	1.8
40	43.3	25.3	4.8	20.0	4.6	2.0
45	41.7	25.9	6.4	18.7	5.0	2.3
50	42.9	25.8	5.6	18.1	5.1	2.4
60	43.1	26.4	6.7	15.0	5.9	2.9
70	43.8	27.1	7.4	11.8	6.3	3.6
80	48.7	29.9	7.0	6.3	4.6	3.3
Residue	49.7	31.9	7.0	3.4	3.4	4.5

Table 6e. S-8.

Distillate volume fraction, %	Paraffins Vol %	Monocyclo- paraffins Vol %	Dicyclo- paraffins Vol %	Alkyl- aromatics Vol %	Indanes and tetralins Vol %	Naphth- alenes Vol %
<i>Composite</i>	80.0	17.3	0.9	0.1	0	1.9
0.025	79.1	18.4	0.1	1.8	0.0	0.6
10	81.2	16.4	0.0	1.9	0.0	0.5
20	81.0	18.0	0.1	0.0	0.0	0.9
30	80.8	17.9	0.3	0.0	0.0	1.1
35	82.0	16.8	0.1	0.0	0.0	1.1
40	85.8	13.7	0.0	0.0	0.0	0.5
45	87.8	11.9	0.0	0.0	0.0	0.3
50	85.3	13.8	0.0	0.0	0.0	0.9
60	85.1	13.9	0.0	0.0	0.0	1.1
70	85.1	13.7	0.0	0.0	0.0	1.2
80	83.6	15.0	0.0	0.0	0.0	1.4
Residue	84.8	14.7	0.0	0.0	0.0	0.5

The distribution of hydrocarbon type as a function of distillate fraction is instructive among the different turbine fuel mixtures. Mixtures that have a high concentration of S-8 are seen to have a very high paraffin content, as expected. This approximate concentration ranges from 75+ % for the mixture that contains 75 % S-8, to 55+ % for the mixture that only contains 25 % S-8. For each mixture, the alkylaromatic content decreases markedly as a function of distillate fraction, and this is especially notable for the mixtures that are rich in Jet-A. For the 75/25 S-8/Jet-A mixture, the alkylaromatic concentration shows a great deal of scatter which results from its very low concentration in mixtures rich in S-8. The concentrations of the indanes and tetralins, and the naphthalenics compounds increase with distillate fraction, and this increase is especially pronounced in the mixtures that are rich in Jet-A.

4. Density (at Atmospheric Pressure) for 50/50 Jet-A + S-8

A Stabinger viscodensimeter (Anton Paar SVM 3000, see Figure 5 below) was used to determine the density in the temperature range from $-40\text{ }^{\circ}\text{C}$ to $100\text{ }^{\circ}\text{C}$ (233.15 K to 373.15 K) at atmospheric pressure (83 kPa at 1654.7 m altitude at Boulder, Colorado). A similar technique was used for measurements on JP-10 and S-8 [18, 19]. The digital density analyzer in the viscodensimeter used a U-shaped vibrating sample tube and a system for electronic excitation and frequency counting. The density of the sample liquid in the vibrating tube was obtained from the resonant frequency of the vibrating system relative to the resonant frequency with a calibration liquid of known density.




Figure 4. A plot of the hydrocarbon types resulting from the ASTM D-2789 analysis for three mixtures of Jet-A-4658 and S-8.

The combination of a viscometer and a densimeter makes it possible to obtain absolute viscosity η as well as kinematic viscosity, ν (which will be presented later in this report) of a sample because $\nu = \eta/\rho$ where ρ is the density. The amount of sample needed for both measuring cells was less than 5 mL. The assembly is thermostatted by a copper block that surrounds both the viscosity and the density measuring cells and kept both cells at the same temperature. A thermoelectric heating and cooling system ensured the temperature stability of the copper block within 0.005 °C from the set temperature at the position of the viscosity cell over the whole temperature range. At temperatures below 0 °C the viscodensimeter was cooled with an additional external circulator. The uncertainty ($k = 2$; 95 % confidence level) of the temperature calibration was no more than 0.03 °C over the range from 15 to 100 °C. Outside this range the calibration uncertainty is no more than 0.05 °C. The density measurements performed with this instrument on the 50/50 (vol/vol) Jet-A + S-8 mixture are provided in Table 7.




Figure 5. Main components of the Stabinger viscodensimeter SVM 3000. (1) Thermostating Peltier block, (2) Concentric cylinder viscometer, (3) Vibrating tube densimeter.

Table 7. Densities of 50/50 (vol/vol) Jet-A + S-8 mixture measured with the Stabinger viscodensimeter SVM 3000. The ambient pressure during the measurements was 83 kPa.

Temperature T	Density ρ	Temperature T	Density ρ	Temperature T	Density ρ
K	kg·m ⁻³	K	kg·m ⁻³	K	kg·m ⁻³
Sample 1 Run 1		Sample 2 Run 1		Sample 3 Run 1	
373.15	719.5	373.16	719.6	373.15	719.9
363.15	727.1	363.15	727.2	363.15	727.2
353.15	734.6	353.15	734.6	353.15	734.8
343.15	742.1	343.15	742.2	343.15	742.2
333.15	749.5	333.15	749.5	333.15	749.5
331.15	750.9	331.15	750.8	331.15	750.9
329.15	752.3	329.15	752.3	329.15	752.3
327.15	753.8	327.15	753.8	327.15	754.0
325.15	755.3	325.15	755.3	325.15	755.5
323.15	756.8	323.15	756.8	323.15	756.8
321.15	758.3	321.15	758.2	321.15	758.3
319.15	759.8	319.15	759.7	319.15	759.8
317.15	761.3	317.15	761.2	317.15	761.3
315.15	762.7	315.15	762.6	315.15	762.7
313.15	764.2	313.15	764.0	313.15	764.2
303.15	771.2	303.15	771.3	303.15	771.3
293.15	778.5	293.15	778.6	293.15	778.5
283.15	785.8	283.15	785.9	283.15	785.8
273.15	793.0	273.15	793.1	273.15	793.1
271.15	794.5	271.15	794.5	271.15	794.6
269.15	795.9	269.15	795.9	269.15	796.0
267.15	797.4	267.15	797.4	267.15	797.4
265.15	798.8	265.15	798.9	265.15	798.9
263.15	800.2	263.15	800.3	263.15	800.3
261.15	801.7	261.15	801.7	261.15	801.7
259.15	803.1	259.15	803.1	259.15	803.1
257.15	804.5	257.15	804.6	257.15	804.6
255.15	805.9	255.15	806.0	255.15	806.0
253.15	807.3	253.15	807.4	253.15	807.4
251.15	808.8	251.15	808.7	251.15	808.8
249.15	810.2	249.15	810.2	249.15	810.2
247.15	811.6	247.15	811.6	247.15	811.6
245.15	813.0	245.15	813.0	245.15	813.0
243.15	814.4	243.15	814.5	243.15	814.4
241.15	815.8	241.15	815.8	241.15	815.8
239.15	817.3	239.15	817.3	239.15	817.2
237.15	818.7	237.15	818.7	237.15	818.6
235.15	820.0	235.15	820.1	235.15	820.0
233.15	821.4	233.15	821.5	233.15	821.4




Figure 6. The density of the 50/50 (vol/vol) mixture of Jet-A + S-8 as a function of temperature at atmospheric (ambient) pressure.

5. Viscosity (at Atmospheric Pressure) for 50/50 Jet-A + S-8

The viscosity measurements with the Stabinger viscodensimeter were carried out according to ASTM Standard D 7042 – 04 *Standard Test Method for Dynamic Viscosity and Density of Liquids by Stabinger Viscometer (and the Calculation of Kinematic Viscosity)*. The following instrument description is partly excerpted from ASTM Standard D 7042 – 04. The viscometer part of the instrument uses a rotational coaxial cylinder measuring system. The outer cylinder (tube) of Hastelloy is driven by a motor at a constant and known rotational speed. The low-density inner cylinder (rotor) of titanium is held in the axis of rotation by the centrifugal forces of the higher density sample and in its longitudinal position by the magnet and the soft iron ring. Consequently, the system works free of bearing friction as found in rotational viscometers. A permanent magnet in the inner cylinder induces eddy currents in the surrounding copper casing. The rotational speed of the inner cylinder establishes itself as the result of the equilibrium between the driving torque of the viscous forces and the retarding eddy current torque. This rotational speed is measured by an electronic system (Hall effect sensor) that counts the frequency of the rotating magnetic field (See figure below).

The uncertainty of the viscosity measurement is stated by the manufacturer as 0.35 % of the measured value and that of the density measurement at $0.5 \text{ kg}\cdot\text{m}^{-3}$, while the repeatabilities are 0.2 % of the measured value and $0.2 \text{ kg}\cdot\text{m}^{-3}$, respectively. However, wide-ranging comparisons of measured viscosities with reference values of viscometer calibrating liquids both in this laboratory and elsewhere have shown that the uncertainty of the viscosity measurements as stated by the manufacturer is not maintained throughout the entire advertised measuring range of the instrument (0.2 to 10,000 mPa·s in absolute viscosity and 0.2 to 10,000 $\text{mm}^2\cdot\text{s}^{-1}$ in kinematic viscosity) with one calibration. The viscosity measurements for three separate aliquots of the Jet-A + S-8 mixture are presented in Table 8 and Figures 8 and 9.




Figure 7. Assembly of the concentric cylinder viscometer in the Stabinger viscodensimeter SVM 3000.

Table 8. The measured viscosity of the 50/50 (vol/vol) mixture of Jet-A + S-8 at 83.4 kPa.

Temp- erature T	Absolute Viscosity η	Kinem. Viscosity ν	Temp- erature T	Absolute Viscosity η	Kinem. Viscosity ν	Temp- erature T	Absolute Viscosity η	Kinem. Viscosity ν
K	mPa·s	mm ² ·s ⁻¹	K	mPa·s	mm ² ·s ⁻¹	K	mPa·s	mm ² ·s ⁻¹
Run 1			Run 2			Run 3		
373.15	0.5217	0.7251	373.16	0.5216	0.7247	373.15	0.5213	0.7241
363.15	0.5794	0.7969	363.15	0.5797	0.7972	363.15	0.5796	0.7971
353.15	0.6489	0.8833	353.15	0.6493	0.8839	353.15	0.6492	0.8836
343.15	0.7297	0.9832	343.15	0.7304	0.9841	343.15	0.7302	0.9839
333.15	0.8254	1.101	333.15	0.8263	1.102	333.15	0.8263	1.102
331.15	0.8483	1.130	331.15	0.8488	1.130	331.15	0.8500	1.132
329.15	0.8705	1.157	329.15	0.8710	1.158	329.15	0.8724	1.160
327.15	0.8936	1.185	327.15	0.8942	1.186	327.15	0.8956	1.188
325.15	0.9177	1.215	325.15	0.9184	1.216	325.15	0.9199	1.218
321.15	0.9690	1.278	321.15	0.9700	1.279	321.15	0.9716	1.281
319.15	0.9964	1.311	319.15	0.9975	1.313	319.15	0.9991	1.315
317.15	1.025	1.347	317.15	1.026	1.348	317.15	1.028	1.350
315.15	1.055	1.383	315.15	1.056	1.385	315.15	1.058	1.387
303.15	1.272	1.649	303.15	1.272	1.650	303.15	1.273	1.651
283.15	1.842	2.344	283.15	1.843	2.345	283.15	1.844	2.347
273.15	2.310	2.912	273.15	2.309	2.912	273.15	2.315	2.918
271.15	2.427	3.054	271.15	2.427	3.054	271.15	2.432	3.061
269.15	2.554	3.208	269.15	2.554	3.208	269.15	2.560	3.215
267.15	2.692	3.376	267.15	2.692	3.376	267.15	2.698	3.383
265.15	2.842	3.558	265.15	2.843	3.558	265.15	2.849	3.567
263.15	3.007	3.758	263.15	3.008	3.759	263.15	3.014	3.767
261.15	3.187	3.976	261.15	3.189	3.978	261.15	3.195	3.986
259.15	3.385	4.215	259.15	3.387	4.217	259.15	3.394	4.226
257.15	3.603	4.479	257.15	3.605	4.481	257.15	3.612	4.490
255.15	3.844	4.770	255.15	3.844	4.769	255.15	3.853	4.781
253.15	4.110	5.091	253.15	4.111	5.091	253.15	4.121	5.104
251.15	4.405	5.447	251.15	4.405	5.446	251.15	4.417	5.462
249.15	4.735	5.844	249.15	4.735	5.844	249.15	4.748	5.860
247.15	5.103	6.288	247.15	5.103	6.288	247.15	5.117	6.305
245.15	5.516	6.784	245.15	5.516	6.784	245.15	5.531	6.803
243.15	5.981	7.343	243.15	5.981	7.343	243.15	5.997	7.363
241.15	6.435	7.888	241.15	6.436	7.888	241.15	6.453	7.910
239.15	7.030	8.601	239.15	7.030	8.602	239.15	7.049	8.625
237.15	7.706	9.413	237.15	7.706	9.413	237.15	7.727	9.438
235.15	8.478	10.34	235.15	8.478	10.34	235.15	8.500	10.37
233.15	9.363	11.40	233.15	9.363	11.40	233.15	9.388	11.43




Figure 8. A plot of the kinematic viscosity of the 50/50 mixture of Jet-A + S-8.




Figure 9. A plot of the absolute viscosity of the 50/50 mixture of Jet-A + S-8.

6. Speed of Sound Measurements (at Atmospheric Pressure) for 50/50 Jet-A + S-8

The speed of sound in liquid samples of S-8 was measured with a sound speed analyzer DSA 5000 that is similar to the SVM 3000 viscodensimeter in design and appearance. It also includes a vibrating U-tube densimeter and a pulse-echo speed of sound measurement cell that is illustrated below. However, the temperature range is limited from 0 °C to 70 °C. The measurement uncertainty is stated for both properties as 0.01 % to 0.1 %, with repeatabilities of 0.001 kg·m⁻³ in the density and 0.1 m·s⁻¹ in the speed of sound measurement. The density measurement in the DSA 5000 is more accurate than that in the viscodensimeter. By design, the densimeter in the viscodensimeter was made only as accurate as necessary in view of the higher uncertainty of the viscosity measurement. This device is shown schematically in Figure 10. The measured values for the speed of sound in the mixture of Jet-A + S-8 are provided in Table 9, and a plot of these values against temperature is provided in Figure 11. Adiabatic compressibilities were obtained from the measured densities and speeds of sound via the thermodynamic relation $\kappa_s = -(\partial V/\partial p)_s/V = 1/(\rho w^2)$, where V denotes volume, p is pressure, and w the speed of sound. Subscript s indicates “at constant entropy s .” The calculated values are also reported in Table 9 and they are plotted in Figure 12.




Figure 10. Schematic of the sound speed measurement in the DSA 5000.

Table 9. Speeds of sound and adiabatic compressibilities of Jet-A + S8 mixture measured in the Sound Speed Analyzer DSA 5000. The ambient pressure during the measurements was 83 kPa.

Temp- erature T	Speed of sound w	Adiab. compres- sibility κ_s	Temp- erature T	Speed of sound w	Adiab. compres- sibility κ_s	Temp- erature T	Speed of sound w	Adiab. compres- sibility κ_s
K	m·s ⁻¹	TPa ⁻¹	K	m·s ⁻¹	TPa ⁻¹	K	m·s ⁻¹	TPa ⁻¹
Run 1			Run 2			Run 3		
343.15	1113.14	1090.16	343.15	1111.09	1094.00	343.15	1109.43	1097.51
333.15	1149.68	1011.70	333.15	1147.65	1015.14	333.15	1145.94	1018.36
323.15	1186.39	940.620	323.15	1184.76	943.116	323.15	1183.18	945.796
313.15	1223.58	875.581	313.15	1222.25	877.310	313.15	1220.87	879.508
303.15	1261.50	815.544	303.15	1260.38	816.698	303.15	1259.13	818.562
293.15	1299.99	760.250	293.15	1299.10	760.929	293.15	1298.02	762.394
283.15	1338.99	709.230	283.15	1338.40	709.468	283.15	1337.51	710.520
278.15	1358.70	685.285	278.15	1358.00	685.069	278.15	1356.78	685.217




Figure 11. A plot of the speed of sound in a 50/50 mixture of Jet-A + S-8.




Figure 12. A plot of the adiabatic compressibility of a 50/50 mixture of Jet-A + S-8.

7. Correlations for the Density, Viscosity, and Speed of Sound of 50/50 Jet-A + S-8

The previously reported experimental results for the density, viscosity, and speed of sound of 50/50 Jet-A + S-8 at ambient pressure were correlated to facilitate their practical application. The temperature dependence of the density and of the speed of sound is each represented by a quadratic polynomial

$$\rho = a_0 + a_1T + a_2T^2, \text{ and} \quad (1)$$

$$w = c_0 + c_1T + c_2T^2, \quad (2)$$

while the temperature dependence of the absolute viscosity requires the more complex formulation

$$\frac{\eta}{\eta_0} = \exp\left(\beta_1 + \frac{\beta_2}{T_r} + \beta_3 \ln(T_r) + \beta_4 T_r^{\beta_5}\right). \quad (3)$$

The adjustable parameters in eqs. (1) and (2) were determined by linear and those in eq. (3) by nonlinear least squares regression. The optimal values are listed in Table 10 with their standard deviations and the applicable temperature ranges.

Table 10: Parameter values and associated standard deviations of the correlations eqs. (1-3) for a 50/50 mixture of Jet-A + S-8.

	Density, eq. (1)		Viscosity, eq. (3)		Speed of sound, eq. (2)	
	233 K $\leq T \leq$ 373 K		233 K $\leq T \leq$ 373 K		278 K $\leq T \leq$ 343 K	
<i>i</i>	Parameter value a_i	Stand. Dev. s_i	Parameter value β_i	Stand. Dev. s_i	Parameter value c_i	Stand. Dev. s_i
0	976.37964	0.44			2659.2926	56
1	-0.62516115	$3.0 \cdot 10^{-3}$	8.0698334	0.58	-5.3967658	0.37
2	$-1.6811101 \cdot 10^{-4}$	$5.2 \text{E} \cdot 10^{-6}$	-8.9055146	0.68	$2.5802235 \cdot 10^{-3}$	$5.9 \cdot 10^{-4}$
3			-8.4990463	0.39		
4			1.6747087	0.10		
5			-4.2001948	0.075		
	Max. dev.	0.029 %		0.69 %		0.073 %
	Min. dev.	-0.028 %		-0.61 %		-0.046 %
	Avg. abs. dev.	0.0076 %		0.20 %		0.026 %
	Std. dev.	0.0098 %		0.26 %		0.031 %

8. Compressed Liquid Density Measurements for 50/50 Jet-A + S-8

A schematic of the apparatus used to measure compressed liquid densities over the temperature range of 270 K to 470 K and to pressures of 50 MPa is illustrated in Figure 13. The heart of the apparatus is a commercial vibrating tube densimeter; however, several physical and procedural improvements have been implemented beyond that of the commercial instrument operated in a stand-alone mode. The densimeter is housed in a specially designed two-stage thermostat for improved temperature control. The uncertainty in the temperature is 0.02 K, with short-term stability of 0.005 K. Pressures are measured with an oscillating quartz crystal pressure transducer with an uncertainty of 10 kPa. The densimeter was calibrated with measurements of vacuum, propane and toluene, over the temperature and pressure range of the apparatus to achieve an uncertainty in density of 1 kg/m³.

The apparatus was designed, and software was written so that the operation and data acquisition are fully automated. Data are taken along isotherms over a temperature/ pressure matrix programmed by the operator prior to the start of measurements. The electronically actuated pneumatic valves and programmable syringe pump are used to move from one pressure to the next and/or flush fresh sample through the system. Operation of the densimeter in this manner allows for measurements to be made 24 h per day. The densimeter described above has been used to measure 121 compressed liquid densities of a 50/50 (vol/vol) Jet-A + S-8 sample from 270 K to 470 K at pressures from 0.5 MPa to 30 MPa. The data are listed in Table 11.




Figure 13. Schematic of the compressed liquid density apparatus.




Figure 14. Compressed liquid densities of Jet-A + S-8 50/50 (vol/vol) mixture as a function of temperature. The measurement results at ambient pressure are indicated by light grey symbols.

Table 11. Compressed liquid density measurements on 50/50 Jet-A + S-8.

Temperature [K]	Pressure [MPa]	Density [kg/m ³]	Temperature [K]	Pressure [MPa]	Density [kg/m ³]
270.00	30.018	812.15	370.00	4.007	726.14
270.00	25.007	809.52	370.00	3.006	725.07
270.00	20.017	806.83	370.00	2.011	723.99
270.00	15.011	804.05	370.00	1.001	722.88
270.00	10.013	801.19	370.00	0.508	722.33
270.00	5.011	798.23	390.00	30.016	737.06
270.00	4.001	797.61	390.00	25.013	732.73
270.00	3.006	797.01	390.00	20.013	728.18
270.00	2.006	796.39	390.00	15.005	723.33
270.00	1.010	795.77	390.00	10.016	718.16
270.00	0.515	795.45	390.00	5.013	712.56
290.00	30.014	799.58	390.00	4.004	711.36
290.00	25.004	796.73	390.00	2.998	710.14
290.00	20.010	793.80	390.00	2.002	708.92
290.00	15.002	790.76	390.00	1.006	707.68
290.00	10.006	787.62	390.00	0.509	707.05
290.00	5.014	784.35	410.00	30.011	724.65
290.00	4.009	783.67	410.00	25.011	719.97
290.00	3.010	782.98	410.00	20.000	714.98
290.00	2.008	782.28	410.00	15.000	709.65
290.00	1.010	781.58	410.00	10.007	703.88
290.00	0.505	781.21	410.00	5.006	697.59
310.00	30.004	786.80	410.00	4.009	696.25
310.00	25.010	783.68	410.00	3.005	694.88
310.00	20.010	780.45	410.00	2.005	693.47
310.00	15.010	777.09	410.00	1.008	692.05
310.00	10.004	773.59	410.00	0.509	691.32
310.00	5.006	769.95	430.00	30.005	712.26
310.00	4.007	769.18	430.00	25.007	707.16
310.00	3.017	768.42	430.00	20.011	701.72
310.00	2.006	767.60	430.00	15.011	695.85
310.00	1.008	766.83	430.00	10.011	689.41
310.00	0.503	766.42	430.00	5.014	682.31
330.00	30.001	774.17	430.00	4.000	680.76
330.00	25.004	770.79	430.00	3.010	679.21
330.00	19.995	767.27	430.00	2.005	677.60
330.00	15.003	763.61	430.00	1.006	675.95
330.00	10.012	759.79	430.00	0.509	675.10
330.00	5.002	755.76	450.00	29.993	700.02
330.00	4.008	754.91	450.00	25.003	694.51
330.00	3.012	754.07	450.00	20.012	688.55
330.00	2.007	753.21	450.00	15.014	682.04
330.00	1.006	752.34	450.00	10.010	674.85
330.00	0.513	751.91	450.00	5.005	666.76

Temperature [K]	Pressure [MPa]	Density [kg/m ³]	Temperature [K]	Pressure [MPa]	Density [kg/m ³]
350.00	30.002	761.73	450.00	4.006	665.01
350.00	25.007	758.07	450.00	3.012	663.21
350.00	20.006	754.24	450.00	2.001	661.33
350.00	15.009	750.23	450.00	1.009	659.42
350.00	10.017	746.02	450.00	0.501	658.41
350.00	5.006	741.53	470.00	30.021	687.99
350.00	4.015	740.60	470.00	25.004	681.96
350.00	3.001	739.64	470.00	20.003	675.41
350.00	2.006	738.69	470.00	14.995	668.18
350.00	1.012	737.71	470.00	10.011	660.13
350.00	0.508	737.21	470.00	5.013	650.91
370.00	30.007	749.41	470.00	4.005	648.87
370.00	25.009	745.44	470.00	3.007	646.76
370.00	20.006	741.26	470.00	2.003	644.58
370.00	15.011	736.85	470.00	1.006	642.31
370.00	10.006	732.18	470.00	0.516	641.16
370.00	5.004	727.18			

9. References

- [1] Handbook of aviation fuel properties, CRC Report No. 635, Alpharetta, GA: Coordinating Research Council (CRC) (2004).
- [2] MSDS, S-8 Synthetic Jet Fuel, material safety data sheet. Syntroleum Corp., Tulsa, OK (2005).
- [3] T. J. Bruno, P. D. N. Svoronos, CRC handbook of basic tables for chemical analysis, 2nd ed., Boca Raton: CRC Press (2004).
- [4] T. J. Bruno, P. D. N. Svoronos, CRC handbook of fundamental spectroscopic correlation charts. Boca Raton: Taylor and Francis CRC Press (2005).
- [5] Standard test method for boiling range distribution of petroleum fractions by gas chromatography, ASTM Standard D2789-02, ASTM Annual Book of Standards (2004).
- [6] Standard test method for distillation of petroleum products at atmospheric pressure, ASTM Standard D 86-04b, Book of Standards Volume 05.01. American Society for Testing and Materials: West Conshohocken, PA (2004).
- [7] T. J. Bruno, Method and apparatus for precision in-line sampling of distillate. Sep. Sci. Technol. 41(2): 309-314 (2006).
- [8] T. J. Bruno, Improvements in the measurement of distillation curves — part 1: a composition-explicit approach. Ind. Eng. Chem. Res. 45: 4371-4380 (2006).
- [9] T. J. Bruno, B. L. Smith, Improvements in the measurement of distillation curves—Part 2: Application to aerospace/aviation fuels RP-1 and S-8. Ind. Eng. Chem. Res. 45: 4381-4388, (2006).

- [10] T. J. Bruno, B. L. Smith, Enthalpy of combustion of fuels as a function of distillate cut: application of an advanced distillation curve method. *Energy and Fuels* 20: 2109-2116 (2006).
- [11] B. L. Smith, T. J. Bruno, Advanced distillation curve measurement with a model predictive temperature controller. *Int. J. Thermophys.*, 2006. 27: p. 1419-1434.
- [12] B. L. Smith, T. J. Bruno, Improvements in the measurement of distillation curves—Part 3: Application to gasoline and gasoline + methanol mixtures. *Ind. Eng. Chem. Res.* 46: 297-309 (2006).
- [13] B. L. Smith, T. J. Bruno, Improvements in the measurement of distillation curves—Part 4: application to the aviation turbine fuel Jet-A. *Ind. Eng. Chem. Res.* 46: 310-320 (2006).
- [14] B. L. Smith, T. J. Bruno, Application of a composition-explicit distillation curve metrology to mixtures of Jet-A + synthetic Fischer-Tropsch S-8. *J. Propul. Power.* (submitted).
- [15] S. Young, Correction of boiling points of liquids from observed to normal pressures. *Proc. Chem. Soc.* 81: 777 (1902).
- [16] S. Young, Fractional distillation. London: Macmillan and Co., Ltd. (1903).
- [17] S. Young, Distillation principles and processes. London: Macmillan and Co., Ltd. (1922).
- [18] T. J. Bruno, The properties of S-8. Final Report for MIPR F4FBY6237G001, Air Force Research Laboratory (2006).
- [19] T. J. Bruno, M. L. Huber, A. Laesecke, E. W. Lemmon, R. A. Perkins, Thermochemical and thermophysical properties of JP-10. *Natl. Inst. Stand. Technol. NISTIR* 6640 (2006).

